OXFORD

Liquid Nitrogen Cryo-Cooler

(Series C)

Operator's Manual

Oxford Instruments
Accelerator Technology Group
Osney Mead, Oxford
Oxon, OX2ODX, England
Telephone: (01865) 269500
Fax: (01865) 269502

Version 3.0

February 1997

Important

This operating manual is intended to help the user operate the Oxford Instruments Cryocooler.

Before attempting to operate the system, **PLEASE READ THE INSTRUCTIONS.**

Warranty

Products of Oxford Instruments ATG are warranted to be free from all defects in materials and workmanship. The liability of Oxford Instruments ATG under this guarantee is limited to servicing, adjusting or re;lacing defective parts. The guarantee is effective for one year from the date of despatch to the original purchaser, provided:

1. The product is returned to the factory, undamaged by failure to provide sufficient packaging.

2. The product appears to Oxford Instruments ATG's satisfaction to be defective through no fault of the user.

3. The equipment has been handled and operated in accordance with the instructions and advice given in this manual or any other instructions which may be provided by Oxford Instruments ATG.

4. A Customer Returns (CR) Authorisation number is obtained from the Customer Service Manager at Oxford Instruments ATG before returning any item for service or repair.

Important Health and Safety Notice

When returning components for service or repair it is essential that the item is shipped together with a signed declaration that the product has not been exposed to any hazardous contamination or that appropriate decontamination procedures have been carried out so that the product is safe to handle.

A suitable form can be obtained on request. As additional security and to facilitate your repair, please send a duplicate declaration by post or fax.

Copyright © 1996 Oxford Instruments. All rights reserved. No part of this document may be reproduced or distributed in any form or by any means, or stored in a data base or retrieval system, without prior written permission of Oxford Instruments.

Contents

1. Introduction 1-1

1.1 Principle of Operation 1-1

1.2 Scope of this Manual 1-1

2. Safety 2-1

2.1 Electrical Safety 2-1

2.1.1 Potential Electrical Hazards 2-1

Electric shock 2-1

Electric burn 2-2

Fires of an electrical origin 2-2

Arcing 2-3

Explosion 2-3

2.1.2 Essential Precautions 2-3

2.1.3. First Aid 2-4

2.2 Safe Mechanical Practice 2-4

2.3. Safe Cryogenic Practice 2-4

2.3.1. Handling Cryogens 2-4

Extreme cold 2-4

Mechanical Strength 2-5

Asphyxiation 2-5

Precautions 2-5

First Aid 2-5

2.3.2. Storage Dewar And Cryostat Hazards 2-5

Condensation of contaminates 2-5

Fire hazards. 2-6

Risk of explosion. 2-6

Warming up of a system. 2-6

2.4. Safe Gas Handling 2-6

2.4.1. Health Hazards 2-6

2.4.2. Essential Precautions 2-6

3. Hardware Description 3-1

3.1 Overall System 3-1

3.1.1 Specifications 3-1

3.1.2 System Layout 3-2

3.1.3 Theory of Operation 3-2

Low Pressure Circuit 3-4

High pressure circuit (Closed Loop Circuit) 3-4

Controls 3-5

Operating Values 3-6

Description 3-7

Drawings 3-10

3.2 Sub-Cooler Vessel 3-10
3.3 Barber Nichols Pump 3-10
3.4 Sub-cooler Coil 3-11
3.5 Cryogenic Valves 3-11
3.6 High Pressure Reservoir and Pressure Control 3-12
3.7 Transfer Lines 3-12
3.8 Control Rack and Instrumentation 3-12
3.8.1 Control Rack 3-14
3.8.2 Power distribution panel 3-14
3.8.3 Rack control unit 3-14
3.8.3.1 Pressure Monitoring and Pressure Control 3-15
3.8.3.2 Temperature Monitoring 3-15
3.8.3.3 Flow monitoring (if fitted) 3-15
3.8.4 Liquid Nitrogen Level Monitoring 3-15
3.8.5 Remote Control and Monitoring 3-16

4. Operating Procedures 4-1
4.1 Switching on the Control Rack 4-1
4.1.1 Connecting the control rack. 4-1
4.1.2 Powering the control rack 4-1
4.2 Initial Cooldown and Fill 4-2
4.3 Initial Start-Up 4-3
4.4 Raising the Closed Loop Pressure 4-4
4.5 Operational Mode 4-5
4.6 Lowering the Closed Loop Pressure 4-6
4.7 Warming up the Optic 4-6

5. Routine Maintenance 5-1
5.1 Daily Checks 5-1
5.2 Monthly Checks 5-1
5.3 Six Monthly Checks 5-1
5.4 Twelve Monthly Checks 5-1

6. Trouble Shooting Procedures 6-1
6.1 Checking the Process Controller Set-up 6-1
6.2 Changing Burst Discs 6-2
6.3 Checking the Control System Operation 6-4
6.3.1 Tools and test equipment needed 6-4
6.3.2. Test Procedure 6-4
6.3. 3 Setting Up the ILM Meter 6-7
6.3.3.1 Entering Test Mode 6-7
6.3.3.2 Test t.05 Configuring the Channels 6-7
6.3.3.3 Test t.07 Setting Probe Active Length 6-8
6.3.3.4 Test t.11 Setting Full, Fill and Low Thresholds 6-9
6.3.4 Final Reminder 6-9
6.4 Checking the Performance of the Complete System 6-11

6.4.1 Tools and test equipment needed 6-11
6.4.2 Objective of tests 6-11
6.4.3 Procedure 6-12
6.5 Procedure for Pumping Out the Bayonets 6-16
6.6 Procedure for Pumping Out the Flexible Lines 6-16

7. Spare Parts List 7-1

8. Additional Documentation 8-1