

# **Micromechanics of Materials using High Energy XRD**

**Ersan Üstündag**

Ames Laboratory and Department of Materials Science and Engineering, Iowa State University

## Collaborators

**Rob Rogan, Jay Hanan, Can Aydiner and Seung-Yub Lee**

Department of Materials Science, California Institute of Technology

**Dean Haeffner, Jon Almer, Ulrich Lienert and Doug Robinson**

Advanced Photon Source, Argonne National Laboratory

**Irene Beyerlein\* and Sivasambu Mahesh**


\*Theoretical and Materials Science and Technology Divisions, Los Alamos National Laboratory

**Mark Daymond**

ISIS Neutron Facility, Rutherford Appleton Laboratory (U.K.)

**Supported by NSF (CAREER and MRSEC), DARPA, ARO and DOE**

# Fracture of a Fiber Composite under Tension



- **Aim**: prediction of strength and lifetime
- **Need**: “realistic” constitutive laws

## Complications

- Fabrication processes
- Inhomogeneous dislocation densities
- Changes in grain size
- Geometrical constraints
- Interface introduced with different properties
- Residual stresses

# Motivation and Approach

---

- ❑ Little information about deformation and **constitutive behavior of materials at multiple length scales.**
- ❑ Need to **link experimental data with rigorous micromechanics modeling.**
- ❑ Approach: Use **X-ray microdiffraction** to investigate deformation in materials and complement it with **modeling.**
- ❑ Critical issues:
  - Need for model specimens
  - “High selectivity” of diffraction
  - Only elastic lattice strains are measured with diffraction
  - Lack of “realistic” constitutive laws to calculate stress and interpret diffraction data

# Advantages of XRD

- Non-destructive.
- Ability to distinguish different phases.
- Can measure elastic strain and texture.
- Simultaneous strain and imaging capability.
- Multi-scale: *nm* to *cm*.
- Deep penetration.
- *In-situ* experiment capability.

⇒ **Determination of *in-situ* constitutive behavior**


Bragg's law:

$$\lambda = 2d \sin \theta$$

Differences in lattice spacing


⇒ **Elastic lattice strain**

$$\varepsilon_{hkl}^{el} = \frac{d_{hkl} - d_{hkl}^0}{d_{hkl}^0} = \frac{d_{hkl}}{d_{hkl}^0} - 1$$




# High Energy 2-D XRD Experimental Setup

Digital image plate




## Critical Issues with High Energy 2-D XRD:


- Deep penetration
- Complete Debye rings captured
- 2-D strain tensor
- Small  $\theta$  values (i.e., high strain error):
  - Sensitive to displacement error
  - Need to employ internal standard




# Model Composite: Ti-6Al-4V / SiC (SCS-6)




- Uniaxial tensile testing
- Damage evolution study using XRD (65 keV)
- Complete penetration
- 90 x 90  $\mu\text{m}^2$  spot size



- Laminar composite: Ideal for model comparison
- 140  $\mu\text{m}$  in diameter fibers; 240  $\mu\text{m}$  average center-to-center distance
- 200  $\mu\text{m}$  thick matrix
- Data collected with a digital image plate



# Multi-Fiber Deformation Model\*




- Shear lag model for 2-D fiber composites
- Accounts for matrix sustaining elastic tensile and shear stresses (*first shear lag model to do so*)
- Allows for multiple fiber and matrix breaks
- Computationally *faster* for many breaks
- Assumes *elastic* deformation only

\* I.J. Beyerlein and C. M. Landis, *Mechanics of Materials*, 1999; 31: 331.

# Matrix Stiffness Shear Lag (MSSL) Model Predictions


- (i)-intact matrix
- (ii)-broken matrix

With  $\rho = 0.289$   
for both one  
and two broken  
fibers






# Location of Diffracting Grains




**SiC (220) map**








- **Ti grain size  $\sim 29\ \mu\text{m}$ :**
  - Few diffracting grains.
- **SiC grain size  $\sim 0.2\ \mu\text{m}$ :**
  - Continuous grain map.
- **Use of full Debye rings to obtain more matrix data.**

**Point detector**




# Finite Element Predictions

Ti-SiC



- The predicted axial strains are ideal for



J. C. Hanan, E. Üstündag et al, *Metall. Mater. Trans.* 33A, 3839-3845 (2002).




AMES LABORATORY


# Unloading Strains in Fibers Compared to the MSSL Model

Ti-SiC


Left Side of the Damage Zone:



Right Side of the Damage Zone:




- Good fit with 'intact matrix' case.
- Unloading strains were used due to plasticity in matrix.
- Right hand side data suggests interface debonding.




# Unloading Strains in the Matrix Compared to the MSSL Model

Ti-SiC


## Matrix between two intact fibers:



## Matrix around damage zone:




- Better fit with 'intact matrix' case.
- $\rho = 0.290$  appears to be a more realistic value.
- Matrix data comes from few grains.




# Matrix Strains Using Image Plate

Ti-SiC


## Axial Strain Map



## Shear Strain Map




## Transverse Strain Map



- Multi-axis strain data
- Significant strain concentrations in matrix


$$\sigma = 850 \text{ MPa}$$






AMES LABORATORY

# Transverse Thermal Residual Strain from FEM

Ti-SiC





- **Tension** over the fibers.
- **Compression** between fibers.



# Change in Matrix *Axial* Residual Strain due to Loading

Ti-SiC

- The compressive regions identify plastic deformation while loading the composite






# Micromechanics of Composites: *Conclusions*

---

- High energy XRD allows rigorous validation of advanced micromechanics models.
- Detailed stress/strain and structure data can be collected at the microstructure scale.
- Possibilities now exist for extensive studies under various loading conditions.
- Composite field will benefit tremendously from combined diffraction and imaging capabilities.



# Constitutive Behavior of Ferroelectric Materials




$$\frac{c}{a} = 1.065$$



High temperature  
(non-polar cubic)

Room temperature  
( $\langle 001 \rangle$  polarized tetragonal)



Six equivalent  $\langle 001 \rangle_{\text{cubic}}$   
directions give six equivalent  
states at room temperature



**Poling**



**Depoling**



- Poling in large electric fields aligns crystallite polarizations through a process called “ferroelectric switching”.
- Applied stress causes de-poling and 90° domain switching.
- Fundamental understanding of the details of domain micromechanics is crucial for accurate modeling of ferroelectrics.

# Self-Consistent Modeling of Ferroelectrics





Fig. 2. The progressive nature of ferroelectric transformation within a crystal due to domain wall motion.

- **Domain switching within a single crystal (grain).**
- **Each of  $M$  ( $=6$ ) variants can transform into any of the remaining  $M-1$  ( $=5$ ) variants: total of 30 transformations ( $90^\circ$  and  $180^\circ$  switches).**
- **Domain wall motion is dissipative (similar to dislocation motion).**
- **Stress ( $\sigma_{ij}$ ) and electric field ( $E_i$ ) are uniform in the crystal.**
- ***There is no hardening.***
- **Dislocation plasticity is neglected.**



Huber, J.E., Fleck, N.A., Landis, C.M. and McMeeking, R.M., *J. Mech. & Phys. Sol.*, **47** (1999) 1663-1697.

# Constitutive Behavior of Polycrystalline $\text{Pb}(\text{Zr,Ti})\text{O}_3$





- Studied electromechanical response of polycrystalline  $\text{Pb}(\text{Zr,Ti})\text{O}_3$
- Employed neutron diffraction and high energy XRD
- Diffraction yields  $hkl$  dependent strains and texture data, information crucial for modeling

# Neutron Diffraction: Lattice Strain Evolution in Two Phase $\text{Pb}(\text{Zr,Ti})\text{O}_3^*$



\* R.C. Rogan, E. Üstündag, B. Clausen, M.R. Daymond, *J. Appl. Phys.* 93[7], 4104-4111 (2003).




# Neutron Diffraction: Experimental Setup at ISIS



- $+90^\circ$  (left) bank observes transverse sample behavior
- $-90^\circ$  (right) bank observes axial sample behavior
- *Very limited detector coverage and slow data collection*



# High Energy XRD at APS Sector 1: 2-D Data

- Samples were electrically poled under sequentially increasing static fields while taking X-ray patterns.
- Results indicate a severe dependence on  $\eta$  and a critical coercive field of  $\sim 0.3$  kV/mm.



# High Energy XRD at APS Sector 1: 2-D Data

- After poling, samples were cycled through positive and negative ranges.
- The typical “butterfly” curve was observed for each azimuthal angle.
- By “caking” 36 virtual detectors were generated to allow a wide coverage of reciprocal space.





R.C. Rogan, E. Üstündag, M.R. Daymond and U. Lienert,  
submitted to *J. Appl. Phys.* (2004).



# Angular Dependence of Strain Behavior


By defining various “spans” the data may be broken down as a function of angle




R.C. Rogan, E. Üstündag, M.R. Daymond and U. Lienert, submitted to *J. Appl. Phys.* (2004).



# 3-D XRD: Domains in a Single Grain of Polycrystalline BaTiO<sub>3</sub>



- Cycled electric field on a pre-poled BaTiO<sub>3</sub>
- Monitored evolution of domain volume fractions and strain within individual grains
- Critical information for 3-D FEM of ferroelectrics



- Domain switching occurs at a low field ( $E_c \sim 0.5$  kV/mm)
- At higher fields spot separation and rotation increases (3-D lattice strain)

# Constitutive Behavior of Ferroelectrics: *Conclusions*

---

- High energy XRD is ideal for micromechanics studies on ferroelectrics.
- Fast electromechanical loading allows *in-situ* investigation of constitutive response.
- 2-D strain and texture data yield multiaxial information about material behavior.
- Development of 3-D XRD capability at APS will add *mesoscale* capability.
- It is possible to perform detailed multiscale, multiaxial studies of ferroelectric micromechanics at APS.