

# X-ray Characterization of Cement-based Materials: Previous Applications & New Opportunities

**Kimberly Kurtis**  
**School of Civil and Environmental Engineering**  
**Georgia Institute of Technology**  
**Atlanta, Georgia**

**Collaborators:**  
**CXRO at ALS: G. Denbeaux, A. Lucero**  
**UC Berkeley: P.J.M. Monteiro**  
**Georgia Tech: A.P. Wilkinson, A.C. Jupe, N.N. Naik**  
**APS: P. Lee**  
**NIST: P. Stutzman**  
**IBNAM at Northwestern Univ.: S.R. Stock**

August 31, 2004

# What are cement-based materials?

Any material that uses a mineral cement as a binder

Classes of mineral cement: portland (calcium silicate-based) and calcium aluminate, some dental and bone cements

Cement paste =



Mortar =



Concrete =



# Why research cement-based materials?

Concrete is the most widely used building material, with more than **12 billion tons** of placed annually.

## Annual Regional Cement Consumption, million tons

	<b>1994</b>	<b>2000</b>	<b>2005</b>
Europe*	313	393	432
Asia	680	853	1000
Middle East	65	79	82
Africa	63	71	77
North America	90	92	92
South&Central America	92	118	142
Misc.	7	9	10
<b>Total</b>	<b>1310</b>	<b>1625</b>	<b>1835</b>

\* *World Cement*, V27(5).


# Why research cement-based materials?

## Increasing infrastructure demands

- increasing population
- construction in more aggressive environments
- increasing performance expectations

## Environmental concerns

- energy consumption
- CO<sub>2</sub> production
- durability



# Why research cement-based materials?

Despite the widespread use of cement-based materials, fundamental understanding is lacking with regard to:

- chemistry and structure during manufacture
- hydration chemistry
- nano and microstructure of cement-based materials
- behavior under load (fracture and creep) and during shrinkage
- structure-property relationships
- durability
- effect of combinations of loading and environmental exposure


These gaps limit our ability to reliably produce cement-based materials with specialized physical and mechanical properties and that exhibit long-term durability.

# Challenges Associated with Characterization of Cement-based Materials

- Hydrated systems that change with removal of water
- Optically opaque materials, but sub-surface or volumetric characterization is often desirable
- Complex materials that are heterogeneous on multiple scales (nano → micro → meso → macro)
- Want to resolve the smallest features of the structure, while still capturing the different spatial structures that comprise the whole
- Effect of time can be important → fast imaging
- Non-destructive characterization is desirable

# Structure of cement-based materials

- Concrete is heterogeneous on multiple scales



1-5 nm

Ult. strength  
Adsorption

<50nm

Shrinkage  
Creep  
Durability

# Applications of X-ray Imaging

- Cement production
- Cement hydration
- Behavior under loading
- Degradation/durability






# Cement Production

$\text{CaCO}_3$  (limestone)

$2\text{SiO}_2 \cdot \text{Al}_2\text{O}_3$  (clay, shale)


$\text{Fe}_2\text{O}_3$  (iron oxide)

$\text{SiO}_2$  (silica sand)



# Cement Production


Studies to date in this area have almost exclusively relied upon synchrotron powder diffraction, rather than imaging.








De La Torre, Bruque, Campo, and Aranda,  
*Cement and Concrete Research*, 32:1347-  
56 2002.

Fig. 1. SXRPD Rietveld plot for  $C_3S$ . The inset shows the fit to the most representative region for  $C_3S$ .

# Cement Production: Would Imaging be Useful?

An analogue in geochemistry: combined  $\mu$ SXRF-  $\mu$ SXRD for elemental mapping on a soil nodule. 

Combined with  $\mu$ EXAFS to examine Zn sequestration.



# Cement Production


Research opportunities exist in:

- Identification of phases existing in unhydrated cement and clinker
- Quantification of those phases
- Characterization of phase structure as influenced by the introduction of hazardous and non-hazardous (introduced for improved production or hydration) impurities
- *In situ* characterization at high temperature (to 1500 C)

# Cement Hydration


When water is added to cement, what happens?

- Dissolution of cement grains
- Growing ionic concentration in “water” (now a solution)
- Formation of compounds in solution
- After reaching a saturation concentration, compounds precipitate out as solids (“hydration products”)
- In later stages, products form on or very near the surface of the anhydrous cement



# Cement Hydration


Very generally, portland cement hydration proceeds by:



# Cement Hydration: EDXRD

- Rapid data acquisition allows for in situ monitoring of cement hydration in real time

An intermediate in the hydration of  $C_3A$  (or  $3CaO \cdot Al_2O_3$ ) was definitively identified using time-resolved EDXRD at Daresbury SRS.





# XM-1: Beamline 6.1.1 at ALS




XM-1 is operated and maintained by the Center for X-ray Optics (CXRO)




# Cement Hydration: TXRM

Examination of hydration of calcium sulfoaluminate cements (Kleinite  $C_4A_3\bar{S}$  or  $4CaO \cdot 3Al_2O_3 \cdot SO_4$ )




30 min.



85 min.

2400x;  $\lambda=2.4nm$


# Cement Hydration: TXRM




Tiles composed from X-ray images of mixture of 30.0%  $C_4A_3\bar{S}$  + 53.4%  $C\bar{S}$  + 16.5% C (by mass) after 4.5 hours in saturated calcium hydroxide + 0.1 M  $CaCl_2$  solution, w/s=10

# Cement Hydration: TXRM


- Investigation of thermal treatment on hydration of low-energy,  $\beta$ -2CaO·SiO<sub>2</sub> rice hull ash cements.
- RHA cements processed at higher temperatures (150°C vs. 130°C) reacted more rapidly, with products visible through TXRM at earlier ages and with greater abundance.



unhydrated



6% Ba<sup>2+</sup>, 150C



6% Ba<sup>2+</sup>, 130C

2400x;  $\lambda=2.4\text{nm}$




# Pozzolanic Reaction: TXRM



- Reaction of finely divided silicates in alkaline calcium-rich solutions generally resulted in products with dendritic microstructure
- The 'sheaf of wheat' morphology was particularly prevalent

Tiled x-ray images of chemical grade silica gel after 2 hours in saturated  $\text{Ca}(\text{OH})_2$  solution.




# Pozzolanic Reaction: TXRM



Reaction of silica gel in 0.7M NaOH + 0.1M CaCl<sub>2</sub> solution over time results in development of “sheaf of wheat” microstructure.

2400x;  $\lambda=2.4\text{nm}$

# Pozzolanic Reaction: Ca-edge Spectromicroscopy using TXRM





# Transmission Soft X-ray Microscopy at XM-1

## Advantages

- Designed for ease of user operation
- Samples can be studied wet
- No artifacts from drying or pressure change
- Able to observe and record ongoing reactions
- High resolution (43 nm)
- Characterization of internal structure
- Identify areas of elemental concentrations

## Limitations

- Small sample size – nearly 2D imaging
- High solution-to-solid ratio needed for transmission
- Limited spectromicroscopy capabilities
- Limited availability

# Cement Hydration: Synchrotron Microtomography




Image: S.R. Stock, Northwestern Univ.


- 5  $\mu\text{m}$  voxels, 21 keV
- Brighter spots are likely calcium hydroxide
- Technique could be useful for quantification in blended cement (portland-pozzolan) systems




# Cement Hydration : Synchrotron Microtomography

Introduction of toluene to cement paste results in large voids or vesicles in the hardened material, likely initially filled with the hazardous organic waste.

(a) 1.24 wt% toluene/cement




(a) 1.24 wt% toluene/cement




(b) 2.49 wt% toluene/cement

vesicle




(b) 2.49 wt% toluene/cement



# Cement Hydration: Synchrotron Microtomography

Very small (~1mm) samples of calcium phosphate (bone) cement on bone have been examined by phase-contrast microtomography.





# Cement Hydration

Research opportunities exist in:

- Nanoscale characterization (structure and composition) of C-S-H
- Coupled imaging and phase identification (diffraction?) in simplified and complex systems at realistic water-to-cement ratios
- Characterization of cement hydration at low and high temperatures and at high temperature and pressure (oil well applications)
- Time-resolved characterization (imaging and quantification) of the effects of chemical admixtures and “green” supplementary cementing materials on reaction kinetics, chemistry, and structure



# Loading

- Establishing true structure-property relationships has been challenging because of the multi-scale heterogeneity of cement-based materials
- Concrete is considered to be a 3 phase material: paste or mortar fraction + coarse aggregate + agg/paste interface



# Loading: Synchrotron Microtomography

- Microtomography at BL X2B (NSLS) was used to examine internal cracking in 4x8 mm cylindrical mortar samples under compression
- Data describing the three-dimensional crack surfaces generated was related to fracture energy, by  $dW/dA = d(F-U-C)/dA$



# Loading

Synchrotron-based research opportunities exist in:

- Fracture in ultrahigh performance “concretes”
- Strength, stiffness measurements of individual components, for modeling complex materials
- Creep in cement paste
- Damage propagation due to combinations of loading and environment




# Durability


- Sulfate attack, including thaumasite formation
- Alkali-silica reaction
- Delayed ettringite formation
- Leaching
- Acid attack
- Carbonation
- Abrasion
- Erosion
- Freeze/thaw
- Fire
- Corrosion of reinforcing steel

# Durability: TXRM


## Alkali-Silica Reaction



“Dry” ASR gel;  
Not in solution



ASR gel in 0.05M NaOH  
at pessimum proportion




ASR gel in 0.7M NaOH at  
pessimum proportion




# Durability: TXRM


Examination of the effect of chemical additives to control expansion by alkali-silica reaction



After 1 week in 0.7M  
NaOH + 10%  
acetone






After 1 week in 0.7M NaOH + 0.1M LiCl



# Durability: Confocal X-ray Imaging

- Optical sectioning is limited to transparent materials




K.E. Kurtis, N.H. El-Ashkar, C.L. Collins, and N.N. Naik, *Cement & Concrete Composites*, October 2003, V.25(7):695-701.


C.L. Collins, J.H. Ideker, and K.E. Kurtis, *Journal of Microscopy*, Feb 2004, V.213(2):149-157.

This material is based upon work supported by the National Science Foundation under CMS-0074874. Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of NSF.


# Durability: Confocal X-ray Imaging



$\text{LiNO}_3$ ,  $\text{Li/Na}=1.0$ , 3 days



$\text{LiNO}_3$ ,  $\text{Li/Na}=1.0$ , 8 days




$\text{LiOH}$ ,  $\text{Li/Na}=0.50$ , 1 day

- Lathlike reaction products apparent at the aggregate/cement interface in the presence of lithium only.
- Technique could also be used for characterization of cement hydration products formed via bottle hydration and at aggregate/paste interfaces

# Durability: TXRM


- *In situ* study of corrosion of steel filings





# Durability: Synchrotron Microtomography



- The first synchrotron imaging of cement-based material found in the literature reports sulfate damage to an epoxy-impregnated 3.5mm-diameter sample cored from a standard mortar bar, as examined by Bentz and co-workers (1995) at BL X-2B at NSLS



Bentz, D.P., Martys, N.S., Stutzman, P., Levenson, M.S., Garboczi, E.J., Dunsmuir, J., and Schwartz, L.M. (1995) *Proc. Microstructure of Cement-based Systems: Bonding and Interfaces in Materials*, Diamond, S., Mindess, S., Glasser, P., Roberts, L.W., Skalny, J.P., and Wakeley, LD. (Eds.), Materials Research Society.

# Durability: Lab-based microtomography with EDXRD

- 70 kVp x-ray tube
- Detector with 2048 x 64 elements and 24 $\mu$ m pitch
- After identifying the top of the sample via scout view, 390 slices were imaged 50 $\mu$ m apart (4.5 hours/sample)




S.R. Stock, N.N. Naik, A.P. Wilkinson, and K.E. Kurtis, *Cement and Concrete Research*, October 2002, V.32:1673-5.  
N.N Naik, A.C. Jupe, S.R. Stock, A.P. Wilkinson, and K.E. Kurtis, *Cement and Concrete Research*, in review.


This material is based upon work supported by the National Science Foundation under CMS-008482. Any opinions, findings, and conclusions or recommendations expressed in this material are those of the author(s) and do not necessarily reflect the views of NSF.

# Durability: Lab-based microtomography with EDXRD


- Type I cement paste-aggregate sample at  $w/c = 0.485$  and exposed to 10,000 ppm of sulfate ions in sodium sulfate solution



7 weeks




17 weeks



29 weeks



# Durability: Lab-based microtomography with EDXRD




	Linear attenuation coefficient, $\mu \text{ cm}^{-1}$							
Time	21 weeks		36 weeks		42 weeks		52 weeks	
	Av $\mu$	Std. dev.	Av $\mu$	Std. dev.	Av $\mu$	Std. dev.	Av $\mu$	Std. dev.
A1	-		-		-		2.0	0.1
A2	-		-		-		1.7	0.2
A3	2.2	0.1	2.0	0.1	2.2	0.1	2.0	0.1
A4	2.3	0.2	2.0	0.1	2.0	0.1	2.0	0.2
A5	-		-		1.3	0.1	1.5	0.1


- A less dense region with darker color is observed near crack C1.
- The less dense region adjoining the crack (A5) is proposed to be due to leaching of calcium hydroxide, decalcification of C-S-H, or some other dissolution process resulting from exposure to the external solution at the cracked surfaces.




# Durability: Lab-based microtomography with EDXRD



- EDXRD performed at XOR's 1 ID at APS




A.C. Jupe, S.R. Stock, P.L. Lee, N. Naik, K.E. Kurtis, and A.P. Wilkinson, *J. Applied Crystallography*, accepted for publication.




# Durability: Lab microtomography with EDXRD

Ettringite-rich, gypsum-free layer  
outside cylindrical crack




Gypsum-bearing region inside crack



N.N. Naik, A.C. Jupe, S.R. Stock, A.P. Wilkinson, and K.E. Kurtis, "submitted to *Cement and Concrete Research*."


A.P. Wilkinson, C. Lind, S.R. Stock, K.E. Kurtis, N. Naik, D.R. Haeffner, and P.L. Lee, *Materials Research Society Symposium 42 Proceedings Series*, V. 678, EE5.3.1, San Francisco, CA, April 14-20, 2001.

# Durability: Lab microtomography with EDXRD *and SEM*



Field of view = 4mm

- Spatial relationship between structure and chemistry is key to understanding underlying damage process



# Durability

Some opportunities for further synchrotron-based research:

- *In situ* imaging for damage process monitoring
  - imaging at variable temperature, RH
- Combined imaging and chemical/phase analysis
  - adequate resolution to capture changes in small capillary pores (5-50 nm) and to detect microcracks
- Post-imaging *quantitative analysis* to measure crack surface area, pore connectivity, etc., which can then be used to link composition and performance
- Simply too many high-value potential applications to list here...



# Concluding Remarks

X-ray imaging affords some clear benefits for the characterization of cement-based materials, including

- Non-destructive examination and/or sectioning of opaque cement-based materials
- High resolution
- Rapid data acquisition
- Characterization of hydrated samples at normal temperature and pressure, if desired.

# Concluding Remarks

Developments which would be beneficial for researchers in the cement-based materials community include:

- Coupling of imaging and diffraction or elemental analysis
- Sample indexing systems which function *between* beamlines
- Dedicated beamlines for imaging, avoiding complicated and time-consuming set up and break down
- User support for imaging, reconstruction, and analysis
- Ability to image larger samples, even at lower resolution
- On-site microscopy/tomography facilities for sample pre-view, to locate regions of interest
- Imaging at resolution  $< 50\text{nm}$