Hard X-ray Science with a Diffraction-Limited Storage Ring

Paul G. Evans evans@engr.wisc.edu

November 20, 2014





Outline

- Technique opportunities arising from transverse coherence
- Science:
 - Energy storage materials
 - Materials processing and mesoscale assembly
 - Fluctuations and dynamics in biological materials
 - Integrating new functionalities in electronics
- Conclusion






Outline

- Technique opportunities arising from transverse coherence
- Science:
 - Energy storage materials
 - Materials processing and mesoscale assembly
 - Fluctuations and dynamics in biological materials
 - Integrating new functionalities in electronics
- Conclusion










Stephan Hruszkewycz, Paul Fuoss, Paul Fenter, Dean Haeffner, Martin Holt, John Freeland, Hoydoo Yoo, Oleg Shpyrko, Stefan Vogt, Juan de Pablo, Ian McNulty, Michael Pierce...





Transverse Coherence of Diffraction Limited Storage Ring Sources

Fundamental limit of source size and divergence depends only on wavelength



$$\varepsilon_r = \text{diffraction limited emittance} = \sigma_\gamma \sigma_\gamma' = \frac{\lambda}{4\pi} = \begin{cases} \text{80 pm @ 1 keV} \\ \text{8 pm @ 10 keV} \end{cases}$$

Coherent fraction = ratio of diffraction-limited emittance to total emittance

$$f_{coh} = \frac{F_{\text{coh,T}}(\lambda)}{F(\lambda)} = \frac{\sigma_{\gamma}\sigma_{\gamma}'}{\sigma_{\text{Tx}}\sigma_{\text{Tx}'}} \frac{\sigma_{\gamma}\sigma_{\gamma}'}{\sigma_{\text{Ty}}\sigma_{\text{Ty}'}}$$

Hard x-rays: atomic-scale wavelength/high momentum, K and L edge atomic edges, weak interaction with matter.





Three Ways to Use Transverse Coherence

- Intense Focused Beams for Local Probes
- Microscopy via Scanned Probes/Ptychography/Coherent Diffraction Imaging
- Fluctuations and Dynamics







Coherence of DLSR's Provides a Vast Improvement in X-ray Imaging

Coherent Diffraction Imaging

- Resolution limited by wavelength and sample stability – not optics.
- Recover real and imaginary parts of refractive index: magnetization, composition, bonding configuration.
- Challenge is to reach atomic scale.






Nanofoam Diffraction Pattern/Reconstruction

A. Barty, et al., Phys. Rev. Lett. 101, 055501 (2008)

Wavelength-Resolution Ptychography

- Scanned-beam ptychography adapts CDI to continuous samples, resolution far better than focused x-ray spot size.
- Improved coherence of DLSRs will allow coherent imaging techniques to reach wavelength resolution.



Polarization Domains in PbTiO₃ Hruszkewycz et al., PRL (2013)






Hard X-ray Imaging

- Image using spot size that matches problem.
- Scan or reconstruct from S(Q).
- Resolution, information, depends on S(Q)

Density, composition, magnetism, strain...








A New Regime of Scattering and Spectroscopy with Nanobeams: nanoXAS, nanoXRF, nanoARPES/APXPS, nanoRIXS


X-ray fluorescence nano-tomography

3D elemental mapping of functional mesostructures




nanoRIXS

Understanding coupled excitations in heterogeneous materials and nanostructures



nanoARPES


Electronic texture and single particle response



Eli Rotenberg, ALS

nano-APXPS

in operando studies of complex interphases



DLSRs will vastly expand the capability and capacity of **scanned** x-ray probes: high flux at resolution approaching 1 nm.

Fast Fluctuations with XPCS

X-ray photon correlation spectroscopy


Chemical, magnetic, and structural fluctuations


Accessible time scale proportional to (coherent flux)²

 100-fold increased brightness improves time resolution by 10⁴


DLSRs enable ns-resolution studies of nm-scale fluctuations

- Reaction-diffusion
- Self-assembly
- Domain wall motion
- Complex order parameters





Skyrmion lattice. Seki et. al. Science 336, 198 (2012).



Skyrmion at Cu L₃ edge S. Roy, ALS, 05/2013

Time to probe 1 ns fluctuations:

Today: 50,000 hours

DLSR + modern BL: 0.05 hours

Dream: Correlation within a single pulse, 10 ps fluctuations:

DLSR + new BL + detector: ~2 hours!!

DLSRs will revolutionize our ability to probe **fluctuations** at molecular length scale and subnanosecond timescales.

Outline

- Technique opportunities arising from transverse coherence
- Science:
 - Energy storage materials
 - Materials processing and mesoscale assembly
 - Fluctuations and dynamics in biological materials
 - Integrating new functionalities in electronics
- Conclusion





Structural and Chemical Imaging of Energy Storage Materials





Opportunity

- Electronic, chemical and atomic structure of energy storage materials control their function.
- Structure evolves during operation and use new understanding to optimize durability, capacity, and discharge rate.


Challenge

Requires in operando nm-resolution chemical and spectroscopic imaging and structure determination.

Unique DLSR Strengths

- in operando 3D tomographic chemical mapping using ptychography/CDI.
- Nanofocusing for in-situ/in-operando experiments and use of a multi-modal approach.


Resolving Oxidation States, Chemical Functionality



particles

Solid-Electrolyte Interface: Structure and Function


What controls the formation, composition, and structure of the SEI?







Fluorescence Nanoprobe



Present capability

Al

Cu

Al

Cu

As

W

As

CuAsW

100 nm

Simulated x-ray fluorescence scanning of semiconductor materials; green = single atomic layer of As

Simulated Si particles with 1 nm³ Pt islands as model for catalysis. Left panels show Si x-ray fluorescence; right panels show Pt fluorescence **Stefan Vogt**

With DLSR it will be possible to resolve individual 1 nm Pt catalyst particles.



Requires: Small focal spot size, high focused flux.



Controlling Materials Exhibiting Nanoscale Order





Opportunity


- New electronic, mechanical, optical physics and devices require control of nanoscale order in electronic, magnetic, and orbital degrees of freedom.
- Non-equilibrium theory beginning to emerge via density functional theory but experiments have been challenging.

Challenge

Now use the macroscopic averages of nanoscale order parameters (e.g. ferroelectric or spin/orbital stripes). Local characterization and control not yet possible.

DLSR Strength

Higher coherent flux, allowing us to probe equilibrium dynamics and transitions driven by external fields.








Nanodomains in Ferroelectric/Dielectric Superlattices


Spontaneous Nanoscale Structural and Electronic "Order"








Domain Coherent Scattering









Speckle Statistics





- Speckle Intensity Depends on Beam Location
- Average Domain Diffuse Scattering Constant

 Intensity statistics match speckle distribution




Binomial distribution (e.g. Hruszkewycz, Phys. Rev. Lett. 109, 185502 (2012))





Decorrelation: "Soft" Domain Dynamics




Slow long-lengthscale rearrangement dynamics.


DLSR will allow fluctuations to be studied at much shorter timescales.






Domains in Restricted Geometries









144 nm island domain coherent scattering



Structure and Dynamics of Mesoscale Assembly





Opportunity

- Materials processing and assembly require dynamics far from equilibrium.
- Interfaces (e.g. liquid/air, polymer/polymer) induce assembly always in dynamic states.

Challenge

- Now have snippets of information, too slow to capture the crucial dynamics.
- Reaction kinetics during the self-assembly process on are nm- and ns-µs, 3-4 orders of magnitude faster dynamics in electrolyte than in vacuum, difficult to investigate at existing SR.


DLSR Strength:

- Coherent beam allows focal spot size to be freely chosen to match system.
- Interrogate the structure evolution at fundamental with coherent x-ray scattering or imaging.


Nanoparticle Assembly

Mesoscale structures for high-density photonics, storage media and nanolithography.

Atomic to macroscopic




Coherent Scattering and Interface Microscopy in Continuous Processes








Now: Step Flow in "Ideal" Systems



Pt (001) step flow during evaporation

Oscillations in coherent scattering


M. S. Pierce, et al., Appl. Phys. Lett. **99**, 121910 (2011).







Materials science: Dynamic studies of crack initiation





resolution



Nanoscale Collective Dynamics in Biomaterials





Opportunity


- Biological function requires motion: ps-to-s scale non-thermal reorganization.
- Structure-dynamics-function relationships for model artificial and biomembranes.

Challenge

- Many degrees of freedom in protein backbones and side chains.
- Collective fluctuations occur on a wide range of time scales from ps to s.
- Functional systems are not periodic.

DLSR Strength

- Simultaneous probe of nanoscale order, assembly, and dynamics via microscopy and scattering.
- Multimodal approach (CDI, TXM, SAXS, XPCS, cryo-TEM) to enhance spatial & temporal resolution and chemical speciation







Rare Events in Complex Non-harmonic Energy Landscapes



Opportunity

Non-equilibrium systems have dynamics with important rare events.

Fluids, glasses, biological dynamics, materials assembly and nanostructure dynamics, long-range order in emerging electronic materials.

Need to bridge kinetics and dynamics.

Challenge:

Key features are randomly distributed in time and space.

Key DLSR features:

High brilliance, quasi-CW: "unclocked" systems.

Simultaneously short length/time scales.

Optical Intermittency in **Quantum Dots** Wang et al., Nature 2009 Domain-Wall Motion Event frequency Magnetic domain simulation Sethna, 10 13 Nature 2001 Avalanche Size





Unstructured Peptides and Amyloid Formation

- Aggregation of unstructured peptides is linked to more than 15 neurodegenerative diseases Alzeihmer's, Parkison's, Down's Syndrome, Huntington's etc, also Type II diabetes.
 - Affecting 4.5 million people in USA ¹.
 - Health care cost > \$50 billion¹.
- Industry Protein aggregation during production, purification and storage.
 - Insulin production.
 - National Institute of Neurological Disorders and Stroke

GNNQQNY Prion Disease



Amyloid β
Alzheimer's Disease

Amylin (hIAPP)
Type II Diabetes




Juan de Pablo, University of Chicago





Nucleation and Growth of Toxic Aggregates




[Padrick SB et al. (2002) Biochem, 41:4694]

DLSR: Coherent scattering in heterogeneous systems during nucleation.

Juan de Pablo, University of Chicago

- Small aggregates
 - nucleate growth of fibrils
 - extremely toxic
- Structure unknown
- Nuclei formation time scales
 - µs to minutes
- The pathways for nuclei formation and growth are unknown.
- Monomer to oligomer to fibrils?




Simulation: shapes distinguished using coherent scattering

Chen, Zwart & Li, PRL 110 195501 (2013)





Integrating new functionalities in electronics




Today's electronics: Static structure of highly ordered crystalline devices.

Today's x-ray experiments match this.

Multiple length scales

problematic.






Advanced Electronics: New Functionalities

Future x-ray experiments: dynamics, heterogeneity, subtle order parameters.





Bragg ptychography of strain fields in devices



- Spatial resolution 6-20 nm
- Images of projected displacement field in 2D

BPP reconstructions consistent with linear elastic models of this stressor / SOI system.

Holt, et. al., PRL, 165502, 2014






3D Bragg projection ptychography

- 3D reconstructions are possible using 2D diffraction data.
- 3D imaging can be done at a lower dose and with a simpler experiment than previously possible.

Internal lattice deformation at SiGe/SOI interfaces are revealed.









Control of Other Degrees of Freedom

Future of information processing needs understanding and control of competing phases in the nano- to meso-scale regime

PCMO Electronic Orbital Phase




Today:



Resonant nanodiffraction from orbital order

Nanoscale Phase Fluctuations



Coherent x-ray speckle from nanoscale orbital order

- DLSRs enable enhancement in spatial resolution, 100x increase in sensitivity, access to ps timescales
- Will enable materials science and materials integration of new degrees of freedom.

Ian McNulty





Conclusion

- Technique Opportunities
 - New nanoprobes
 - Nanometer-scale microscopy with beam size matching problem
 - Improved time resolution in fluctuating systems
- Scientific implications span a vast range of problems.



